

## BMP 3.03: IDDE DRY WEATHER FIELD SCREENING

## BMP 3.04: ILLICIT DISCHARGE INVESTIGATIONS AND RESPONSE

## BMP 3.07: PUBLIC REPORTING

May 2024

### Background

Generally, there should be no flow coming from an outfall during dry weather. If the flow contains pollutants, it is considered an illicit discharge and must be eliminated.

Sometimes there may be dry weather flow but it does not contain pollutants, and as such is simply a discharge. Some examples of allowable discharges include uncontaminated groundwater or stormwater that is discharged from building foundation drains, utility vaults/tunnels, recirculating water pump failures, water line breaks, irrigation water, air conditioner condensate, uncontaminated groundwater that seeps into the system naturally, water from fire-fighting activities, and discharges specifically authorized by a NPDES permit. All of the allowable discharges are infrequent, occur in the event of an emergency, or are necessary for proper maintenance and/or safety.

EHS has previously walked accessible areas of the receiving streams adjacent to both City and East Campuses for the purpose of identifying all outfalls that are greater than 8 inches in size, regardless of configuration or type. Identified outfalls have been inventoried, photographed, and uploaded to the University of Nebraska-Lincoln GIS database. Information in GIS includes GPS coordinates, unique identifier numbers, and attributes (e.g., closed pipe/open channel, material of construction, shape, and size). Dry weather inspections have been conducted at each of these outfalls annually since 2007.

Over the course of several years of dry weather inspections approximately 30% of outfalls are found to be flowing with most flowing at a trickle or less. These flows are usually void of pollution indicators and are generally attributed to groundwater seepage, landscape irrigation, or air conditioner condensate. Other flows previously identified but since abated (re-directed away from the storm sewer system) include swimming pool/fountain discharges and non-contact cooling tower water discharges. Considering the University of Nebraska-Lincoln's campus make-up, land uses, geology, geography, and past experiences related to illicit discharges and dry weather inspections, following are the most likely sources of illicit discharges:

- Construction activities, particularly improper site dewatering activities (accumulated storm water or ground water in excavations) and concrete/masonry washout.
- Wet cleaning of exterior locations prone to fouling, such as loading docks and dumpster staging areas.

## **Components of the EHS IDDE Program**

The EHS IDDE program consists of the following activities:

- Regular inspections of high priority facilities and construction sites to detect and abate conditions which could lead to an illicit discharge.
- Prompt response to reports from the community of known or suspected illicit discharges.
- Dry weather inspections of outfalls.

The purpose of this IOP is to describe the manner in which EHS conducts dry weather inspections and discharge investigations. Regular inspection of high priority facilities and construction sites are beyond the scope of this IOP and are described in IOPs specific to those activities.

## **Purpose of Dry Weather Inspections**

The University of Nebraska-Lincoln SMS4 Stormwater Management Plan contains a commitment to conduct annual dry weather inspections of all safely accessible outfalls 8" or greater in size. The purpose of these inspections is to identify and characterize dry weather flows and eliminate illicit discharges. This IOP contains the procedures used by EHS to meet this objective.

## **Preparation for Dry Weather Inspections**

Dry weather outfall inspections are conducted by a team of two EHS staff members. At least one of the team members shall be qualified and trained to conduct IDDE inspections. The other staff member will serve as an assistant. Prior to conducting dry weather inspections, the qualified EHS staff member shall review the prior year's dry weather inspection report for each outfall, as well as historical records for the past three years related to any discharge investigations for each outfall. Dry weather inspections

are to be conducted a minimum of 48 hours after a rainfall event of 0.1" or more. Up to 72 hours may be required following a very heavy precipitation event.

The EHS team shall notify EHS office staff when they will be conducting inspections and their expected time of return to the office. Many of the inspections are performed on steep terrain and injury is possible. If the team has not returned by the expected time, the informed EHS office staff will know they need to check on the well-being of the inspectors. Dress appropriately to enhance safety, e.g., long sleeved shirt, hat, long pants, socks, and boots. Insect repellent is also recommended.

Assemble the following support materials prior to setting out to conduct an inspection:

1. Digital camera or other means of capturing a digital photo of the outfall
2. Several sheets of white paper
3. Each individual must have a means of communication to summon help if needed (e.g., cell phone) and have or program an emergency call list
4. Tool for opening manholes
5. Several clean, clear containers
6. Several clean dippers
7. Nitrile gloves (use when collecting samples for analysis)
8. Flash light or head lamp
9. Backpack or other tote for carrying supplies
10. Clip board, Sharpie markers, and pens
11. Map of the outfall locations with their unique identifier number
12. Map of the UNL storm sewer system to assist in identifying up-gradient pipes, manhole covers, and inlets associated with outfalls that may require an illicit discharge investigation
13. Copy of the prior year's dry weather inspection for each outfall

14. Field screening meter(s), kits, or test strips, as appropriate

### Safety Considerations

Stream banks can be slippery and terrain hazards may not be readily apparent. Wild animals may also be present. The preferred time of year for conducting dry weather inspections is early spring when foliage is at a minimum and before spring rains, but conditions may require an extension to fall in the event there are late freezes or early spring rain. Inspectors shall never bodily enter any closed-pipe portion of the storm water conveyance system.

### Flow Characterization

Considering past observations and configurations of most University of Nebraska-Lincoln outfalls, it is sufficient to characterize flow qualitatively. Flow is characterized as: trickle, low, moderate, or high. The EHS inspector will photograph each accessible outfall that has a flow characterization other than “Not Flowing” as part of the annual dry weather inspection. The inspector will take additional photographs as needed to document physical indicators of pollutants and receiving stream impacts.

### Physical Examination

When safely accessible, don nitrile gloves and collect a sample from a flowing outfall in a clean, clear container and evaluate whether there are any indicators of potential pollutants using visual and olfactory evaluation. Sample bottles and dippers may be reused for another outfall only if rinsed clean before the next use. If the flowing outfall is not accessible, obtain a sample from the nearest, safely accessible sampling location up-pipe from the outfall. Record observations on the inspection form.

- **Odor:** The odor expected from a clean storm sewer could be characterized as ‘wet earth’ or ‘moss like.’ It should not be offensive. Offensive odors can be characterized as:
  - Sewage – such as that detected around improperly operating septic systems.
  - Rancid/sour – similar to that of rotting food in a dumpster.
  - Petroleum – an odor like gasoline, diesel fuel or ‘solvent like’ that may be accompanied by a sheen.

- Sulfide – such as the smell of natural gas or rotten eggs.
- Other – note any other offensive odors as appropriate.
- **Color:** Note the color of the water. Place a sheet of white paper behind the sample container to assist in accurately identifying the color. The combination of color and turbidity can provide clues as to the source of the discharge. For example, a bright green discharge may indicate anti-freeze while a gray, turbid discharge may indicate a source involving concrete or rock.
- **Turbidity:** Turbidity refers to the cloudiness of the water and usually indicates solids that are suspended in the water. A common source of turbidity is eroded soils, sediment and mud. Describe the turbidity (e.g., appearance of chocolate milk, faint white, milky appearance, etc.).
- **Sheen:** Petroleum products and oils can produce a sheen that sits on top of water, and appears shiny, iridescent, and swirly. Look for a sheen in the flow at the outfall, in the receiving water immediately below the outfall. Describe the appearance of the sheen. Iron-eating bacteria can also cause a sheen. Unlike an oil sheen, a bacterial sheen will break into clumps or shatter when disturbed. Make note of how the sheen behaves when disturbed.
- **Suds/Foaming:** Excessive foaming or suds most often suggest the presence of soaps or detergents. Foaming can also indicate decaying algae. In some instances, foaming from decaying native plant material has been observed. Describe observed suds/foaming.
- **Trash:** Make note of the nature of trash observed that appears to have originated from the outfall (e.g., napkins, food containers, food waste, etc.).
- **Other:** Record any other observation that may be pertinent to the outfall evaluation or IDDE investigation.

## Test Parameters

The following analytical data will be collected for outfall flows identified as moderate or heavy that have no visual or olfactory indicators of potential pollutants. The purpose of field screening is to obtain sufficient data to assist in future evaluation and identification of potential sources of dry weather flows, and to evaluate whether an apparently clean dry weather flow may be “illicit.”

When there are visual or olfactory indicators of potential pollutants in an outfall from an unknown source, field screening will not be conducted. Rather, the primary objective will be identification and elimination of the source as described in Section IX, Source Identification.

Test strips and a portable handheld temperature/conductivity meter will be used for field screening. A pH meter may also be used if a more accurate pH reading than what is provided by the test strips is helpful. All meters will be checked by calibration either once in the morning or prior to sampling. Meters reading +/-10% outside of the calibration standard will fail the calibration check and a full meter calibration will be conducted pursuant to the meter's manual.

A full meter calibration will occur after new probes are installed. Grab samples that are measured with a meter will be sampled within 15 minutes of collection. Commercially available test strips will be unexpired and used following the label instructions for the following parameters:

- pH (range of 1 -14)
- Individual or multiple parameter (such as 5 in 1) test strips will be used for free chlorine, total chlorine, total hardness, total alkalinity, pH (narrow range of 6.2 – 8.4).
- Ammonia range of 0-6 ppm
- Nitrate test strips range 0 – 50 or 500 ppm. Indicate Nitrite reading if the test strip includes a nitrite parameter

The Lincoln Water System 2023 annual report lists the following typical average values for tap water in Lincoln, Nebraska:

- pH 7.8
- Total alkalinity 169 ppm
- Total hardness 192 ppm
- Nitrate + Nitrite varies between 0.2 ppm to 1.1 ppm
- Chloramine averages 2.36 ppm but can also vary between (0 – 3.56 ppm)

Low pH indicates an acidic condition. High pH indicates a basic condition. Common sources of high pH include latex paints, cementitious materials, and cleaners/detergents.

Ammonia is produced by the decomposition of plant and animal proteins and is also a main ingredient in fertilizers. The presence of ammonia in surface water usually indicates contamination from fertilizers, sanitary wastewater, or a commercial/industrial source. Trace amounts of ammonia over time can be toxic to fish and higher ammonia concentrations can result in low dissolved oxygen concentrations and fish kills.

Chlorine is often an indicator of potable drinking water. Chlorine and Chloramine are often added as a disinfectant and is generally present in potable water at concentrations of around 2 ppm.

The City of Lincoln potable water system uses chloramine instead of chlorine. Chlorine test strips are still accurate for chloramine. Chloramine is more chemically stable and off gases at a slower rate than compared to chlorine. Aquatic life is sensitive to chlorine and chloramine, even at levels common to potable water. Under state surface water quality standards, residual chlorine limits for a one-hour average are in the range of 11 to 19 ppb.

Hardness is a measurement of the dissolved mineral content (primarily calcium and magnesium) of water. Hard water contains a high mineral content and soft water contains low mineral content. In areas where hardness levels are elevated due to local geology, hardness can help distinguish between natural groundwater flows and tap water which is typically a low hardness. Natural sources of hardness include limestone.

Nitrate pollution is commonly attributed to discharges from human sewage, livestock manure, fertilizer runoff, landfills, and the erosion of natural deposits. Nitrate and nitrite concentrations can occur in potable waters systems in low concentrations. The drinking water numerical limit for nitrate is 10 ppm and the limit for nitrite is 1 ppm. High nitrate readings can indicate illicit sanitary cross connections or other illicit discharges. Increased nitrate and nitrite levels in stormwater runoff promote algae growth and eutrophication in lakes and streams.

Alkalinity is a measure of the buffering capacity (ability to neutralize acids and bases) of a water body. It can be used along with pH, hardness, temperature, and conductivity, as an indicator of an industrial wash water discharge.

Conductivity is a measure of how well water can conduct an electrical current based on ionic activity and content. Saline waters will have a high conductivity, as well as polluted waters. A reading greater than 2000 uS/cm may be indicative of potential

pollutants.

High temperature changes in the receiving water body can adversely impact aquatic habitat near the outfall. The state surface water quality standard indicates the receiving water should not be increased by a total of more than 5°F (3°C) from natural background.

## Source Identification

Inspections are conducted to identify the source of moderate or heavy flows, or flows that are suggestive of an illicit discharge through physical examination (e.g., odor, color, turbidity, sheen, suds). In general, the preferred method for conducting a follow-up investigation is to identify potential sources based on observations made at the outfall and evaluating the storm sewer map to identify areas that contribute to that particular outfall. In some cases, it may simply require driving or walking the contributing area to identify the likely source. For example, dewatering at a particular construction site may be easily associated with a turbid water discharge.

In some cases, the potential source may not be obvious and it may be necessary to sequentially inspect up-gradient inlets and manholes starting from the outfall until the source is identified.

Once the source is identified, the EHS staff member shall immediately contact the manager of the department/facility/contractor responsible and coordinate the actions necessary to eliminate present and future discharges. Present discharges shall be stopped as soon as possible. EHS staff is responsible for recording all actions taken to eliminate the discharge, including dates/times of persons contacted, persons responsible for the discharge, nature of the discharge, estimates of quantity and duration of the discharge, etc. (see documentation and recordkeeping). As necessary, EHS shall initiate the Enforcement Response Plan to eliminate the discharge.

In the event of an incident that discharges a pollutant that is not an immediate threat to human health or the environment to or from the City of Lincoln county limits (the adjacent MS4 to University of Nebraska-Lincoln), EHS will contact the City of Lincoln Lancaster County Health Departments (LLCHD) 402-441-8040 and indicate to the operator that the discharge is to or from an adjacent MS4 within 48 hours. EHS will then contact the Superintendent of Stormwater Watershed Management via [watershed@lincoln.ne.gov](mailto:watershed@lincoln.ne.gov) or 402-441-7771 also within 48 hours. If either LLCHD or the City of Lincoln Watershed department perform a follow-up investigation, EHS will ask for courtesy notification of findings and add such to the permit files.

Analytical laboratory testing beyond that described in Section VIII generally will not be necessary. However, if such testing and analysis is deemed necessary or helpful, then samples shall be collected and analyzed in accordance with 40 CFR Part 136.

### **Outfall Condition – Both Flowing and Non-Flowing Outfalls**

The inspector will evaluate the items described below for each outfall. Appropriate follow-up actions for newly identified/worsening conditions are also described. The EHS inspector will photograph and document outfall damage and any new, existing or worsening outfall conditions at the time of inspection and will include the photo in the report.

- **Outfall Damage:** Wear over time is to be expected with all outfalls. Steel pipes can rust. Concrete can etch and crack. Plastic can photo-oxidize and crack. Note damage such as extreme etching or corrosion. If the damage is such that repairs may be needed, the inspector will report it to UNL's Utilities Department for their assessment and follow-up. Damage observed to city owned outfalls will be reported to the City of Lincoln transportation and utilities watershed Management. If there is bank erosion, the inspector shall report it to the Lower Platte South Natural Resource District and make record of this report.
- **Heavy Deposits/Stains:** Oil and paint stains are signs of an illicit discharge and need investigation. Flow lines may be a sign of illicit discharges depending on the circumstances. Rust colored or darkened moss/algae/lichen flow lines are not an issue unless they are excessive. White flow lines may indicate concrete or rock dust discharges. The inspector shall attempt to identify the source by conducting a visual inspection of up-gradient inlets/manholes as described Section IX, Source Identification. It may also be helpful to consult with other UNL Departments as appropriate (e.g., Utility Services, Building Systems Maintenance, Athletic Facility Directors, etc.).
- **Abnormal Vegetation:** Conditions to be alert to when evaluating this item are: excessive algae in the outfall or immediately below the outfall; vegetation immediately downstream of the outfall that is flourishing compared to vegetation immediately upstream of the outfall; vegetation immediately downstream of the outfall that is unexplainably stressed (denuded, burned leaves, stunted, discolored). These conditions may suggest discharge of nutrients or toxic substances. In the absence of staining/deposits and flow, it is unlikely that the source can be identified. However, the inspector shall review UNL's storm sewer maps to identify facilities that have the potential to contribute to the identified condition and consult with appropriate department representatives to determine if

a condition at their particular facility may be a contributing factor. Often, it may be necessary to consult with Landscape Services to determine if any ground-keeping activities have potential to contribute to the condition observed.

- **Sediment Accumulation:** Heavy sediment accumulations shall be documented, and the inspector shall attempt to identify the source. If the likely source is transient (e.g., construction activity), then the primary corrective action may be removal of accumulated sediment. If the likely source is permanent, then the primary corrective action will focus on removal of the source or implementation of effective BMP(s). The inspector shall involve other departments as needed to achieve appropriate corrective action(s).

## Documentation

The inspector shall document all follow-up actions, including the means/methods by which a discharge was investigated, date/time of the follow-up investigation, reason for delaying any investigation that was not initiated immediately after completing the outfall inspection, persons contacted and date/time of contact, sampling details, and final resolution/conclusions with the rationale used to support the final conclusions. Include any photos taken of outfall flow, damage, or other condition noted in the report in this section.

## Reports of Potential Illicit Discharges (Including Spills/Dumping)

EHS will respond to reports of spills/dumping to UNL's storm sewer system. Potential emergency contacts are provided in the table below.

Organization	Telephone Number	Role/Responsibility
Nebraska State Patrol (NSP)	402-479-4921	Multi-agency points of contact after normal business hours
Nebraska Department of Environment and Energy (NDEE)	402-471-2186 (normal business hours) Contact via NSP after normal business hours	Immediate notification required for any spill, release, or dry weather flow believed to be an immediate threat to human health or the environment
University Police	402-472-2222	Primary emergency authority for events on campus (traffic control, evacuation, perimeter security, etc.)

UNL Landscape Services	402-472-1550 (normal business hours)	Has heavy equipment that may be needed to mitigate on-going releases/spills
UNL Utility Services	402-472-4014 (normal business hours)	Knows location of and can access and activate utility shut-off valves. Operates and maintains UNL's storm sewer system.
Lincoln Fire & Rescue HazMat Team	911 or 402-6000	Provide primary directives to all other emergency response personnel when there is substantial threat of harm to persons, the environment, and property; ensures the incident is controlled to the point that it is no longer an emergency.
Lincoln Police Department	911 or 402-441-6000	Coordinates with UNL under Mutual Aid Agreements; Primary emergency authority for events occurring off-campus.
US Coast Guard National Response Center	800-424-8802	Releases of hazardous substances in quantities greater than the Reportable Quantity must be reported to the NRC
City of Lincoln Utilities and Transportation Watershed Management	402-441-7771	Manages the City of Lincoln MS4 permit, associated city utilities and construction stormwater permits adjacent to the University.
Lincoln Lancaster County Health Department	402-441-8000	Assesses public health implications; advises LFR of public health implications and recommendations for evacuation and other responses; advises on remedial actions; enforcement authority for illicit discharges (LMC 28.02)
Nebraska State Fire Marshal	402-471-2027 (normal business hours) 402-471-4545	Provides expertise and instruction if there is threat of fire or explosion.

## Recordkeeping

All dry weather inspections and follow-up actions must be documented either on the form included in Appendix A or by other equivalent means. Paper documents and pictures will be maintained in the Warehouse 1 Building (NPDES→ Year → BMP 3.03 Dry Weather Inspections). In addition, the documentation for each campus will include all outfalls and then be scanned for electronic filing. This informational report will be maintained by EHS in Doc Records, the proprietary records storage application used by EHS.

Records of reports of dumping/illicit discharges are to be maintained as paper documents in the Warehouse 1 Building (NPDES→ Year → BMP 3.04 Illicit Discharges). This informational report will be maintained by EHS in Doc Records, the proprietary records storage application used by EHS.

If the form in Appendix A is required in an accessible format, please request from [ehs@unl.edu](mailto:ehs@unl.edu), including the name of the document, IDDE Response and Dry Weather Screening, noting in the email that you need an accessible version of the Appendix A form.

**Appendix A – Recordkeeping Form**

<b>Section 1: Background Information</b>		
Reason for Inspection: <input type="checkbox"/> Dry Weather Inspection <input type="checkbox"/> IDDE report (Record details- date and time of report, name of person submitting report, nature of the suspected illicit discharge, suspected source, etc.; or attach initial written report as received):		
Outfall #:	Date of Inspection: <b>Click or tap to enter a date.</b>	
Time (military):	Date and amount of Last Significant Precipitation:	
Inspected by:	<input type="checkbox"/> Flowing <input type="checkbox"/> Not flowing (skip to section 5) <input type="checkbox"/> Submerged	
Notes:		
<b>1.1.1 Section 2: Qualitative Flow Characterization</b>		
<input type="checkbox"/> Trickle <input type="checkbox"/> Light <input type="checkbox"/> Moderate <input type="checkbox"/> Heavy		
Notes:		
<b>Section 3: Physical Examination of Flow</b>		
<b>(Attach photo documentation if there are physical examination indicators of an illicit discharge, including in stream effects, if any)</b>		
Sample location:		
Observed? Y/N	Parameter	Describe (including whether the condition is observed at the outfall, within the receiving stream (and distance downstream), or both)
	Odor	
	Color	
	Turbidity	
	Sheen	
	Suds/Foaming	
	Trash	
	Other	

Section 4: Screening Data			
(if moderate or heavy flow, but Section 3 indicates no pollution, complete Section 4)			
Sample location:			
Parameter	Meter Make/Model	Result	
Temperature			
Conductivity			
Parameter	Lot No. of test strips/reagents	Result	
Multiple Parameter Test Strip			
Free chlorine			
Total chlorine			
Total hardness			
Total alkalinity			
pH			
Individual Test Strips			
Ammonia			
pH (1 -14 range)			
Nitrate / (Nitrite if applicable)			
Information for all tests that were not immediately conducted in the field (parameter, date/time of analysis, method of preservation, person/lab conducting the test, test method, etc.):			
Section 5: Outfall Condition			
(Attach photo of outfall; if a condition is noted, include additional photos as necessary to document the condition)			
Observed? Y/N	Parameter	Condition observed previously?	Describe and including any changes from previous observations
	Physical Damage		
	Heavy Deposits/Stains		
	Abnormal Vegetation		
	Heavy Sediment Accumulation		

**Discharge Investigation Documentation**

Provide records (including maps if appropriate) describing all follow-up actions, including the means/methods by which a discharge was investigated, date/time of the follow-up investigation, reason for delaying any investigation that was not initiated immediately after completing the outfall inspection, persons contacted and date/time of contact, sampling details, and final resolution/conclusions included.